
WIDE ANGLE LIGHTHEAD MANUAL

Surface Mounting

WIRING



OPERATION

For Simultaneous or Alternating Flash:

- 1. Apply +VDC to **RED** and **YELLOW** wires simultaneously to enter Grouping mode; lighthead will display short (single or double) flashes:
 - Single flash = Group1
 - Double flash = Group2
- 2. Remove YELLOW wire from +VDC then momentarily apply +VDC to change Groups:
 - Heads of the same Group will flash together.
 - Heads of different Groups will flash alternately.
- 3. Save and Exit the Grouping Mode by powering off the lighthead.

For Flash Patterns:

Momentarily apply +VDC to YELLOW wire:

- once for next pattern
- quick three times for FP#1

NOTE: This unit may not be factory set at FP# 1.

1 Double [R65] 9 Double [SA 2 Single [2Hz] 10 Triple [SAE	
2 Single [2Hz] 10 Triple [SAE	L]
2 Single [2Hz] 10 Triple [SAE]]
3 Triple [2Hz] 11 Quad [SAE]
4 Quad [2Hz] 12 Quint [SAE]]
5 Random 13 Ultra [SAE]	
6 Steady 14 Single-Qua	d
7 Single [SAE][CA13] 15 Single H/L	
8 Mega [SAE] 16 Singe-Triple	e-Quint

Side Mirror Mounting

ADJUSTABLE RANGE FOR SIDE MIRROR MOUNT

Up-down tilting: ±8°

2 Left-right tilting: ±8°


B Height Adjustment: 8mm









WIDE ANGLE LIGHTHEAD MANUAL








Feed the wires through the cable grommet and assemble the Bracket • with Bracket •.



NOTE: You may adjust the Up-down tilting at this point.

2 Attach the Bracket 2 to the Lighthead.



NOTE: You may adjust the height and Left-Right tilting at this point.

Secure the back Cover with the screw and the rubber stud.

