


R65 MINI LIGHTHEAD Manual

Surface Mount

To +VDC (fuse @ 1A) **RED**

To Chassis Ground **BLACK**

For Synchronization **YELLOW**



Connect **YELLOW** wires of multiple lightheads together for synchronization
(All heads should be set at the same Flash Pattern)

For Simultaneous or Alternating Flash:

1. Apply +VDC to **RED** and **YELLOW** wires simultaneously to enter Grouping mode; lighthead will display short (single or double) blips:
 - . Single flash = Group1 . Double flash = Group2
2. Remove **YELLOW** wire from +VDC then momentarily apply +VDC to change Groups:
 - . Heads of the same Group will flash together.
 - . Heads of the different Group will flash alternately.

For Flash Patterns:

Momentarily apply +VDC to **YELLOW** wire:

- . once for next pattern
- . quick three times for pattern 1

NOTE: This unit may not be factory set at FP# 1.

Flash Patterns

Flash Patterns	
1	Single (R65)
2	Double (R65)
3	Triple (R65)
4	Quad (2Hz)
5	Steady