

## Surface Mount


To +VDC (fuse @ 1A)..... **WHITE**

To Chassis Ground..... **BLACK**

For Synchronization:..... **BROWN**

Connect **BROWN** wires of all heads together for synchronization.

(All heads should be set to the same pattern)



**NOTE:** When using adhesive mount, ensure that the mounting surface is clean, dry and well unified before mounting.

## For Simultaneous or Alternating Flash:

1. Apply +VDC to **WHITE** and **BROWN** wires simultaneously to enter Grouping mode; the lighthouse will display short (single or double) flashes:
  - Single flash = Group1
  - Double flash = Group2
2. Remove **BROWN** wire from +VDC and momentarily apply to +VDC to change Group:
  - Heads of the same Group flash together.
  - Group1 heads alternate with Group2 heads.

## For Flash Patterns:

Momentarily apply +VDC to

**BROWN** wire:

- once for next pattern
- quick three times to reset to FP#1

**NOTE:** This unit may not be factory-set at FP#1.

FP#	Flash Patterns			
1	Single	[2Hz]	13	Single H/L (Split)
2	Double	[2Hz]	14	Single [SAE]
3	Triple	[2Hz]	15	Double [SAE]
4	Quad	[2Hz]	16	Quad [SAE]
5	Random		17	Quint [SAE]
6	Single (Split)		18	Mega
7	Double (Split)		19	Ultra [SAE]
8	Quad (Split)		20	Single-Quad
9	Quint (Split)		21	Single H/L
10	Mega (Split)		22	Steady Half
11	Ultra (Split)		23	Steady All
12	Single-Quad (Split)			

\*Split = Left alternating Right