MINI LIGHTHEAD Manual

Surface Mount

To +VDC (fuse @ 1A)..... WHITE _

To Chassis Ground......BLACK_

For Synchronization:.....BROWN_

Connect **BROWN** wires of all heads together for synchronization

(all heads must be set at the same pattern)

For Simultaneous or Alternating Flash:

1. Apply +VDC to WHITE and BROWN wires simultaneously to enter Grouping mode; lighthead will display short (single or double) flashes:

Single flash = Group1
Double flash = Group2

- Remove BROWN wire from +VDC and momentarily apply to +VDC to change Groups:
 - · Heads in the same Group flash together.
 - · Group1 Heads alternate with Group2 Heaads.

For Flash Patterns:

Momentarily apply +VDC to **BROWN** wire:

- once for next patternquickly three times for
- pattern 1

NOTE: This unit may not be factory set at FP#1.

FP#	Flash Patterns		
1	Single (2Hz)	13	Single H/L (split)
2	Double (2Hz)	14	Single (all) (SAE)
3	Triple (2Hz)	15	Double (all) (SAE)
4	Quad (2Hz)	16	Quad (all) (SAE)
5	Random	17	Quint (all) (SAE)
6	Single (split)	18	Mega (all)
7	Double (split)	19	Ultra (all) (SAE)
8	Quad (split)	20	Single-Quad (all)
9	Quint (split)	21	Single H/L (all)
10	Mega (split)	22	Steady Half
11	Ultra (split)	23	Steady All
12	Single-Quad (split)		

^{*}SPLIT = Left alternate Right

^{*}ALL = Simultaneous